FIRST ESTABLISH IF BRACELET IS 1, 2 OR 3 BELOW AND THEN PROCEED AS INDICATED

1. SLIDING CLASP

the direction

iii) slide clasp along

indicated.

bracelet to

iv) When in selected position, locate tabs on the back of clasp into slots on the bracelet and snap down/close the clip

properly and should be re-located.

[see procedure (ii)].

IMPORTANT To avoid straining the clip do not use excessive pressure. If resistance is found when closing clip, the tabs are not located

2. ADJUSTABLE CLASP

To set the bracelet to the required length, depress the end pin of the spring bar as indicated below using a pointed instrument

SPRING BAR



3. LINK ADJUSTMENT

as (A) on the diagram.

suitable clasp slot.

Some of our bracelet models are now fitted with a multiple clasp system which is designed

to make bracelet adjustment easier for you. To reduce the size of the bracelet simply open and remove the adjustable clasp indicated

Note: Adjustable clasps will vary in style depending on the watch bracelet design.

Some adjustable clasps can be finely adjusted by opening the clasp and re-locating into

take this gauge with your watch to that retailer for bracelet

adjustment.

following procedure should be adopted.

Should you feel that your bracelet is too long or too short, the

(i) Complete your name and address overleaf and send with your

watch direct by registered post to Service Department, T.P. (UK)

Ltd, Alexander House, Chartwell Drive, Wigston, Leicester LE18

(ii) Alternatively, if purchased from a High Street jewellers shop,

of charge. Please do not send presentation box as this will not be

2EZ where it will receive immediate attention. This service is free

